

## **Meter Setter and Re-setter UFR Model Number Adders – Please Call the Factory for Pricing & Availability**

---

### **Single Check and Non-Check**

To add the Unmeasured-Flow Reducer (UFR) to 3/4" or smaller setters or resetters with angle single check valves, the following should be added to the end of the model number:

*Example:        20-207WCDD 33 (setter with standard single check valve)  
                     20-207WCDD 33X910 (setter with UFR single check valve)*

- X910    UFR angle single check valve for volumetric (PD) meter
- X911    UFR angle single non-check valve for volumetric (PD) meter
- X912    UFR angle single check valve for volumetric (PD) meter with pentagon test plug
- X913    UFR angle single non-check valve for volumetric (PD) meter with pentagon test plug
- X920    UFR angle single check valve for multi-jet meter
- X921    UFR angle single non-check valve for multi-jet meter
- X922    UFR angle single check valve for multi-jet meter with pentagon test plug
- X923    UFR angle single non-check valve for multi-jet meter with pentagon test plug

### **Dual Check**

To add the Unmeasured-Flow Reducer (UFR) to 3/4" or smaller setters or resetters with angle dual check valves, the following should be added to the end of the model number:

*Example:        20-207WDDD 33 (setter with standard dual check valve)  
                     20-207WDDD 33X970 (setter with UFR dual check valve)*

- X970    UFR angle dual check valve for volumetric (PD) meter
- X971    UFR angle dual check valve for volumetric (PD) meter with pentagon test plug
- X980    UFR angle dual check valve for multi-jet meter
- X981    UFR angle dual check valve for multi-jet meter with pentagon test plug